



**EZ-ON  
PRODUCTS**

# 100TM- TETHER MOUNT

For Family / Passenger Vehicles

## INSTALLATION INSTRUCTIONS

### IMPORTANT INFO

- Meets FMVSS 213 when used with a compatible EZ-ON vest; model 303Z or 403PB.
  - Do not use with non-EZ-ON vests.
- Installation of 100TM requires the use of a tether anchor.
  - Use the vehicle's factory-installed (or EZ-ON's tether hardware kit) tether anchor.
  - If the vehicle manufacturer states a tether anchor weight limit and the child exceeds that weight, install/use EZ-ON's tether hardware kit (unless the vest is used in Positioning-Device Mode, per instructions, as described below).
  - Instructions for EZ-ON's hardware kit are included on the kit's assembly bag; video instructions are also available at [ezonpro.com](http://ezonpro.com).
- 100H (Hardware Kit) not included.
  - If you know you will need the 100H, it must be requested at the time of purchase. However, it can be purchased on its own if you already have the product.
- Recommended replacement: 6 years after date of manufacturing.
- Passengers using EZ-ON transportation vest systems that include this mount:
  - Must weigh 31 lbs.-168 lbs.; if over 168 lbs., see Positioning-Device Mode, below.
  - Must utilize a seat belt, per vest instructions.
  - Should not ride in a booster seat.
  - May use Positioning-Device Mode if height is 4'9" or taller. In this mode, the occupant's vest is attached to the mount for support and the vehicle lap-shoulder belt is worn, following vehicle manufacturer instructions, over the vest.[DJD4] (Note: Passengers who weigh more than 168 lbs. and meet the height requirement (4'9") must use this mode; shorter passengers who weigh over 168 lbs. should not use this product.



### WARNING

Death or serious injury can occur if manufacturer's instructions are not followed correctly. Read below warning information for replacement recommendations.



### REGISTER

Register this transportation vest to be notified of a safety recall.



### WARRANTY

EZ-ON Products stands behind the products we make. Warranty covers any defects in material or workmanship under normal use during the warranty period. We will repair or replace product defects for 1 year from manufacturer date.

**WARNING:** All EZ-ON products are dynamically tested to meet NHTSA standards. Replace product if it is damaged, frayed, or has been in a crash. Recommended replacement period is six years. EZ-ON Products are not liable for injury if these recommendations are not followed.

### CUT ALONG DOTTED LINE FOR EMERGENCY RELEASE



**100 SCBC  
EZ-ON Safe Cut  
Belt Cutter**



### EMERGENCY CUTTING

When evacuating the passenger in a safety vest, the vest webbing is never cut. One cut of the mount webbing above the anchor will allow the passenger to evacuate the vehicle wearing the safety vest and one cut of the lap belt.

605 Commerce Way West  
PO Box 660  
Jupiter, FL 33458

**561.747.6920**  
[cs@ezonpro.com](mailto:cs@ezonpro.com)

**EZONPRO.COM**



## INSTALLATION INSTRUCTIONS

Check the vehicle owner's manual to locate factory installed tether anchor. Instructions for hardware kit are found in the Tether Kit assembly bag.



1. Locate the tether anchor bracket.



2. Attach snap hook of tether mount to car's tether anchor.



3. Place the "Y" of tether mount over back of the seat.



4. Tighten strap by pulling webbing through tilt lock adjuster.



5. With passenger properly seated (hips low against back of seat and shoulders flush to seat). Attach each snap hook at end of the "Y" to tether slots in shoulder adjusters.



6. Reduce tether slack by lifting tilt lock adjuster upward. Slide the webbing to loosen or tighten.

*Note: If passenger is over 4'9," may use seatbelt as intended by vehicle manufacturer. Skip steps 7-9*



7. Thread vehicle belt through vest loops.



8. Buckle belt low on the lap. Secure seatbelt as tightly as possible. Make sure the seat belt is in a locked position.