

43YC

CAR CAM WITH CROTCH STRAP

INSTALLATION INSTRUCTIONS

IMPORTANT INFO

- Meets FMVSS213
 - Installation of 43YC requires the use of a tether anchor.
 - Use the vehicle's factory-installed (or EZ-ON's tether hardware kit) tether anchor.
 - If the vehicle manufacturer states a tether anchor weight limit and the child exceeds that weight, install/use EZ-ON's tether hardware kit.
 Instructions for EZ-ON's hardware kit are included on the kit's
 - assembly bag; video instructions are also available at ezonpro.com.
- 100H (Hardware Kit) not included.
 - If you know you will need the 100H, it must be requested at the time of purchase. However, it can be purchased on its own if you already have the product.
- Passengers using EZ-ON transportation vest systems 43YC:
 - Must weigh over 31-106lbs
 - 。 Must utilize a seat belt, per vest instructions.
 - 。 Should not ride in a booster seat.
- When heavy clothing, like winter jackets, are worn, the vest must be worn underneath.
- Recommended replacement 6 years after date of manufacturing.



ONE SIZE 31-106 LBS



WARNING: All EZ-ON products are dynamically tested to meet NHTSA standards. Replace product if it is damaged, frayed, or has been in a crash. Recommended replacement period is six years. EZ-ON Products are not liable for injury if these recommendations are not followed.

CUT ALONG DOTTED LINE FOR EMERGENCY RELEASE



605 Commerce Way West PO Box 660 Jupiter, FL 33458

561.747.6920 cs@ezonpro.com

EZONPRO.COM

Check the vehicle owner's manual to locate factory installed tether bracket. 43YC tether strap can be turned one half twist to snap on difficult anchor locations.

43YC

4. Prior to seating the passenger, place all of the straps on the front of the seat. Ensure gray strap is laying across bottom of the seat cushion.

5. Seat passenger on the gray strap, so that it extends forward from between the passenger's legs. Place the adjustable black straps in front of the passenger's body.

WARNING: Do not shorten the shoulder straps too much. This can cause the lap belt to be over the stomach causing injury.

Exceptional Safety Solutions for Transporting Children and Adults.

INSTALLATION INSTRUCTIONS

2. Connect tether hook to

tether anchor bracket


directly behind passenger.

Twenty degrees from "Y center is acceptable.



3. Tighten by pulling on black webbing so Y-bridge sits on seat top.

6. Thread the vehicle seat belt through the first chest strap, then the gray crotch strap, and then through the second strap.








1. Locate the tether

anchor bracket.





7. Buckle seat belt low across

the lap and reduce the belt

slack. Make sure seat belt is

in the locked position.



8. First adjust the gray crotch strap from the top of the seat, by pulling on the loose webbing.



9. Adjust the shoulder straps by pulling down on the loose webbing.



10. Clip chest clip, and position at armpit level.







