



EZ-ON PRODUCTS

1-800-323-6598

EZ-ON

FOR SCHOOL BUS USE ONLY

www.ezonpro.com

100SMU

SEAT MOUNT - Fits All Bus Seats

IMPORTANT INFO

- Meets FMVSS213.
- Use Only with EZ-ON Vests Compatible Vest include: 103Z, 203PB, 303Z, 403PB.
- Use on school bus seats that have entry between the seat bottom and the seat back.
- **WARNING!** This restraint must only be used on school bus seats.
Entire seat directly behind must be unoccupied or have restrained occupants.
- Register this Seat Mount to be notified of a safety recall.

WARRANTY

EZ-ON Products stands behind the products we make. Warranty covers any defects in material or workmanships under normal use during the warranty period. We will repair or replace product defects for 1 year from manufacturer date.

WARNING

Death or serious injury can occur if manufacturer's instructions are not followed correctly. All EZ-ON products are dynamically tested to meet NHTSA standards. Please follow washing instructions on product tag. Replace product if it is damaged, frayed, or has been in a crash. Recommended replacement after six years.

EZ-ON Products are not liable for injury if these recommendations are not followed.

EMERGENCY RELEASE PROCEDURE

When evacuating the passenger in a safety vest, the vest webbing is never cut. One cut of the portable seat mount webbing below the buckle will allow the passenger to evacuate the bus wearing the safety vest.

EMERGENCY CUTTING



100 SCBC

EZ-ON Safe Cut Belt Cutter






100SMU

SEAT MOUNT - Fits All Bus Seats

INSTALLATION INSTRUCTIONS



1. Unlock seat and lift up.
2. Hang adjustable hooks from top of seat.
3. Close bus seat. Make sure non-adjustable hook ends are extending on seat bottom.
Note: Securely lock seat bottom in place.
4. Connect push button.
Note: Face of Push Button should be against the bus seat back.
5. Adjust length of seat wrap so that the bar slide is at the top of the bus seat, and non-adjustable hook ends are extending approximately 2 inches on seat bottom.
6. Back thread loose end of webbing through bar slide.
7. Pull webbing tight at the push button. Mount strap must be tight without slack.
Note: Webbing should be tight enough to create a crease on the top of the bus seat.
8. Properly seat passenger.
Note: Hips low against the back of the seat and shoulders flush to the seat.
9. Attach the non-adjustable tether hooks to the "D" rings located at the hip level of the seating passenger's vest.
10. To shorten or lengthen the hip tether hooks, rotate seat mount.
Note: Passenger should not be able to move bottom more than 2 inches forward.
11. Attach adjustable hook ends to tether slots on the shoulder adjusters on the vest.
12. Tighten strap by pulling webbing through the tilt lock adjuster.
Note: Repeat steps 11 - 12 for second shoulder strap.